

Einbauanleitung**Fitting instructions****Istruzioni di montaggio****Notice de montage****Instrucciones de montaje****Monteringsanvisning****CORTECO**

BMW 1er/1 series (E81-E87)
BMW 1er/1 series (E82) Coupe
BMW 1er/1 series (E88)
BMW 3er/3 series (E90;E91)
BMW X1 (E84)

80000063**80000064**

09.04 →

10.07 →

03.08 →

01.05 →

10.09 →

**The Perfect Change.** < 10 min