





HOOK




9x3 mm
9x4 mm








BAYONET



アダプター交換 Adapter Replacement












SIDE PIN




PINCH TAB





アダプター交換
Adapter Replacement




TOP LOCK




アダプター交換 Adapter Replacement




1




2




3




4




5




6




7




8



9



PUSH BUTTON




19 mm




LYNX
auto


アダプター交換 Adapter Replacement




1




2




3




4




5




6




7



8





9



BAYONET RN












アダプター交換 Adapter Replacement




PIN LOCK



アダプター交換 Adapter Replacement



PUSH BUTTON












16 mm




LYNX
auto

アダプター交換 Adapter Replacement



CLAW



アダプター交換 Adapter Replacement

