

## Crankshaft damper

Technical Bulletin - December 2009

## How do you check the condition of a crankshaft damper

- 1) On a cold and stationary engine, draw a diagonal line across the crankshaft pulley using a white marker or chalk.
- 2) Start the engine, accelerate and decelerate for a period of 30 seconds and check the diagonal line for alignment.



The diagonal line drawn across the diameter of the damper must be in line!







SKF/OE strongly recommend to replace both Crankshaft damper and Timing system at the same time without waiting for damper damage!

Typical applications with a low service life and a high risk of engine breakdown

CAR MAKER	ENGINE	ENGINE CODE
PSA	1.9 D, 1.9 TD 2.0 HDI	XUD9, DW8, DW10
VAG	1.9 SDI 1.9 TDI	AGP, AEY, AQM, AGR, ALH
RENAULT	1.9 dTi, 1.9 dCi	F9Q

<sup>®</sup> SKF is a registered trademark of the SKF Group.

The contents of this publication are the copyright of the publisher and may not be reproduced (even extracts) unless prior written permission is granted. Every care has been taken to ensure the accuracy of the information contained in this publication but no liability can be accepted for any loss or damage whether direct, indirect or consequential arising out of the use of the information contained herein.



<sup>©</sup> SKF Group 2009